



**INSTALLATION INSTRUCTIONS  
FOR  
S-124K4**

**PARTS NEEDED:**

Rev. 10-2018

<b>41-230</b>	<b>SAFE-T-PLUS</b> unit (Blue)
<b>S-124K4</b>	<b>Mounting Hardware Kit</b> consists of:
	55-124-6      Anchor Bracket
	55-208        Tie Rod Bracket
	12-38-2000K   3/8 X 2" U-Bolt Kit

Thoroughly clean the section to tie rod before attaching bracket.

- Step 1.        Set front wheels of vehicle to a straight ahead position. This is **IMPORTANT**. Later adjustment of the Tie Rod Bracket may be avoided if front wheels are set perfectly straight.
  
- Step 2.        Remove nuts from front axle passenger side spring rear U-Bolt. Install 55-124-6 and re-tighten nuts securely. Install large end of unit to top of Anchor Bracket. Align holes and insert one of the 3/4" bolts provided, using a flat washer on the opposite side of the unit eyelet from the bracket.
  
- Step 3.        Install 3/4" locknut to mounting bolt and tighten with a wrench to 120-130 foot pounds of torque.
  
- Step 4.        Install Tie Rod Bracket to the bottom of tie rod on the driver's side.
  
- Step 5.        Attach the unit to tie rod by sliding Tie Rod Bracket to align the nearest 3/4" hole in the bracket with unit eyelet on small end. Insert 3/4" bolt provided through aligned holes. Using a flat washer on opposite side of unit eyelet, fasten locknut and tighten to a point allowing the unit eyelet to easily rotate around mounting hole.
  
- Step 6.        Rotate Tie Rod Bracket around tie rod so that the small diameter end of the SAFE-T-PLUS unit is approximately 1/2" lower than the large end of the unit.  
  
                  When positioned, tighten the four (4) U-Bolt nuts to 20 foot pounds of torque while maintaining an even amount of threads extending past each nut.
  
- Step 7.        Tighten 3/4" bolt & locknut on the Tie Rod to 120-130 foot pounds of torque after tightening U-Bolts.
  
- Step 8.        Check to be sure installed unit clears all other parts of vehicle by turning steering wheel to both extremes right and left positions. If unit scrapes or binds at any point,

review these instructions and make necessary corrections by rotating unit on the tie rod to obtain necessary clearance.

Step 9. **ROAD TEST & ADJUSTMENT PROCEDURES** – Step-by-Step instructions are provided herewith separately.

If you need additional technical assistance, please call our technical support team us toll-free at (800) 872-7233 or email us at [support@safe-t-plus.com](mailto:support@safe-t-plus.com).



**Spartan Chassis – Liberty**

**Newmar    Ventana  
Fleetwood    Revolution**